

# C8304-USB

USB and 3,5mm replacement PCB



# Installation Manual

## C8304-USB

Take the original PCB.  
One plastic part need to be removed and used with the new interface.



Remove the cover plastic tongue. Use a screwer, act on the two slits to shift out the plastic as shown in picture.



Take the front plastic removed in the previous step and mount it on the new interface. Make all the connections and replace in the car housing.

