System Firmware Update Instructions for SPH-DA01

NOTE 1: If you have any difficulty carrying out these instructions, please contact Pioneer Customer Support Center.

NOTE 2: Once upgraded to this version, it is not possible to downgrade to a lower version.

NOTE 3: Update resets all the settings and registered contents are reset to the default settings.

! Make sure to have installed version 2.63 before performing this update !

A. Check the current firmware version of your unit:

1. Switch on your AppRadio by switching on the ignition of your car.
2. Select "Settings"
3. Select "General"
4. Check the "Software Version"

If the version number is **2.64** or higher, it is not necessary to update the firmware. If the version number is less than **2.64** or the "Software Version" setting is not visible, it is necessary to update the firmware. Please continue to Step B.

B. Download the firmware ZIP file from Pioneer's website:

Download the file **"SPHDA01_V264.zip**" from the website to a folder on your computer.

C. Create the System Firmware Update microSD card:

MicroSD card requirements:
- MicroSD or microSDHC, 512 MB or more in capacity
- Should be blank and formatted in FAT

PROCEDURE:

1. Connect the MicroSD card to your computer.
2. Double click the ZIP file named **"SPHDA01_V2.64.zip"** to open it.
3. Extract and save the folder **"CE66"** to the root directory of your micro SD card
4. Confirm the folder name and the file size is correct on the micro SD card. To check the file size in Microsoft Windows, select the folder, press the right mouse button, and select "Properties". In OS X, select the folder, press the command+I. If the file name and size do not match the ones listed below, perform steps A and B again.

CE66   Size On Disk: 43.8MB (45,997,841 bytes)

NOTE:

If the correct files are not copied to the microSD card, your AppRadio will not recognize it as an update microSD card and you will not be able to carry out the update.

C. Update the SPH-DA01's system firmware:

REMARKS:

- ✓ **Do not turn off or disconnect the power, or remove the microSD card while the upgrade is in progress, as this will cause the upgrade to stop and might cause additional updates to fail.**
- ✓ If you have any problem during the update process, please contact Pioneer Customer Support Center.

1. Turn on the power of the SPH-DA01.
2. Wait until the "Home Screen" is displayed

3. Insert the microSD card and press the Hardware Reset Button (left of the micro SD card slot) with a pointed object such as the tip of a pen or tweezers.
4. Startup completes in about 30 seconds.
5. Update version confirmation appears automatically. Press the 'arrow' button

(left X.XX = current version <-> right X.XX = version to be installed = 2.64)

REMARK: if the left version is lower then 2.63, then first update the unit to 2.63

6. Update Caution appears, press "OK" to accept the caution agreement and to proceed. MPU Update is executed.

   Do not turn off the power during the update. The update will take approx. 30 seconds to complete.

7. After the update ends ("Update succeed"), the SPH-DA01 will reboot automatically.

8. The "Update completed" screen is displayed. Confirm that the unit was updated to the correct version. (MPU: **V2.64**)

✓ If the version has not been upgraded to the latest version, then perform the system firmware update again.
✓ If the progress message "LOAD OS FILE ERROR. PLEASE UPGRADE OS AGAIN", appears, then please contact our customer support center.

9. Remove the microSD card from the microSD Card slot and power-off the SPH-DA01.

Contact Information

Pioneer Customer Support Center

http://www.pioneer.eu

Copyright(c) 2013 Pioneer Corporation